2 Flow cell stability check

2.1 Touch "MENU"
Touch "Maintenance"
Touch "FLOW-CELL STABILITY"
Check the value of "IR" by printed rolled paper.
If the leek of flow-cell occurs, the values are variable.
*Normally the values of "IR" are all zero. If any values other than "0" is printed, replace flow cell

Parameters	Results	Acceptable Range	Status
Calibration Low	0.000	0	Pass

Paste the "Flow cell stability" printed roll paper here

<<FLOW-CELL>>
09/09/20 14:42
#0000 V0.57

S.G.	R	G	B	IR	TEMP
1.004	21	51	23	0	26.3
1.004	21	51	23	0	26.3
1.004	21	51	23	0	26.3
1.004	21	51	23	0	26.3
1.004	21	51	23	0	26.3
1.004	21	51	23	0	26.4
1.004	21	51	23	0	26.4
1.004	21	51	23	0	26.4
1.004	21	51	23	0	26.4
1.004	21	51	23	0	26.4
1.004	21	51	23	0	26.4
1.004	21	51	23	0	26.4
1.004	21	51	23	0	26.4
1.004	21	51	23	0	26.4
1.004	21	51	23	0	26.4
1.004	21	51	23	0	26.4
1.004	21	51	23	0	26.4
1.004	21	51	23	0	26.4
1.004	21	51	23	0	26.4