

Required Volume of Working Solution (ml)	Quantity of Tubes Required/Minimum Free Space (ml)	Quantity of Serum (ml)
250 ml	67 ml	250 ml
500 ml	80 ml	500 ml
1000 ml	80 ml	500 ml
2000 ml		

NOTE: Handle with care

CENTRIFUGE



REMI



Sl. No.	Name of the Operator	Date

TBS INDIA TELEMETRIC AND BIOMEDICAL SERVICES
 Call on 011-26111111
 Sl. No. of Equipment: 1015
 For further details refer: www.tbsindia.com

TBS INDIA TELEMETRIC AND BIOMEDICAL SERVICES
 PPM Performed on 10/05/2024
 PPM Performed by Raju
 Next PPM Due 9/15/25